
11
CPU
12
Bridge
13
System memory
LAN Controller
14
16
BIOS-ROM
Physical access routine
101
15
Bridge
ODD
17
18
Keyboard controller
181
Power supply switch
RAID
RAID card
19
20
20
20
HDD
HDD
HDD

FIG. 1


A
Setup support system distribution CD
Simple operating system
111
112
Setup support utility
113
Physical access driver
B
OS distribution CD
OS setup module
121
OS to be installed
122
101
Physical access routine
BIOS
100
20
HDD
Setting parameters
Various kinds of hardware

FIG. 2


Main menu
Setup :
Start server setup wizard
a1
Utility :
Individually activate tools for server setup and maintenance
Document :
Display document files
End
Main menu
Setup support system is a tool for simplifying complexity for server hardware setting to OS installation.
Setup :
You can construct RAID in hard disks and install OS in series of processes. Simple setting with simplified and automated operations is available.
Utility :
Utility includes auxiliary function for manual installation and setup information setting function which allows administrators to define setup contents in advance.
Document :
You can open folders containing document files.
Details

FIG. 3


Simple RAID setting
Select type of RAID
a2
RAID 0 (1 to 5 HDDs are usable)
RAID 1 (2 HDDs are used)
RAID 5 (3 to 5 HDDs are usable)
Allocate HDDs
Settable number of HDDs
a3
Set number of HDDs
MAX
a5
a4
a6
<Back
Next>
Main menu
Simple RAID configuration
Input type of RAID configuration and number of hard disks to be used for RAID configuration.
In simple RAID configuration, one array group is formed.
Details
0
50
100
1/n windows are set

FIG. 4


Disk partition setting
Select file system
a7
FAT16 (4Gbyte)
NTFS
Input partition size
4096
Mbyte
a4
<Back
Next>
Main menu
Generation of disk partition
Select file system and size of partition in which Xxxxxx Server 2003 should be installed.
4,096 Mbytes or more can be designated as partition size.
Details
0
50
100
2/n windows are set

FIG. 5


User information setting
User name :
Organization name :
Product ID/CD key :
Computer name :
a8
a4
<Back
Next>
Main menu
User information
Input your name, name of company, name of section to which you belong, CD key or product ID of Xxxxxx Server 2003, and computer name of server.
Following symbols cannot be used in computer name
?"/<>*|:¥;[];+=,.
"(double quotation mark) cannot be used in any items.
Details
0
50
100
3/n windows are set

FIG. 6


Power on
Set parameters for setup
S1
Physically write setting parameters in HDD as OS installation destination
S2
Construct RAID configuration
S3
Generate disk partition
S4
Restore setting parameters (convert setting parameters into files under management of OS)
S5
Install OS
S6
End

FIG. 7